

TocWATCH II Quick Guide



Second hand shows
36 seconds, lcd shows
40 seconds

If your watch isn't showing the correct time, here's a simple process to correct it. First you re-calibrate the watch, then synchronise it.

RE-CALIBRATION

(Aligning the hands)



Step 1 - Hold down the top right button for approximately 7 seconds until hands start advancing round.



Step 2 - Monitor the watch and stop the hands at approximately 11.58, by pressing the bottom right button momentarily




Step 3 - Press the bottom right button repeatedly until the hour, minutes and seconds hands all point to 12.00.00 exactly. **If you go past 12.00, go back to step 1.**

SYNCHRONISATION

(Receiving the latest time signal)





Step 4 - Press the top right button momentarily to start the synchronisation. The second hand will advance round 1 minute. The  symbol will start flashing.



Step 5 - Place the watch stationary, preferably on its side, by a window **away from computers, mobiles, electronic devices and any power cables.**



Step 6 - The  symbol will appear on the watch, indicating the time signal has been received (**usually takes 3-4 minutes**). If there is no  symbol go to **step 8**.



Step 7 - The hands automatically adjust to the correct time

For further support either view a short video at www.businessimage.co.uk/tocwatch2video or contact us directly at sales@businessimage.co.uk or telephone 01293 518299, where they'll be happy to help you.

If after following steps 1-7, your watch isn't showing the ✱ symbol, you should re-synchronise the watch, to receive the latest time signal.

RE-SYNCHRONISATION (2nd attempt to receive the latest time signal)



Step 8 - Hold down the bottom right button for approximately 3 seconds until the second hand advances to 00 seconds. The ✱ symbol with start flashing



Step 10 - The ✱ symbol will appear on the watch, indicating the time signal has been received (usually takes 3-4 minutes).



Step 9 - Place the watch stationary, preferably on its side, by a window **away from computers, mobiles, electronic devices and any power cables.**



Step 11- The hands automatically adjust to the correct time

If the ✱ symbol still doesn't appear, it's most likely because there isn't a good signal from the atomic clock. You will need to find an area of better reception. For the technically minded, the UK time signal is long wave and transmitted from North Cumbria, at 60 KHZ.

To get the best reception:

- Keep watch stationary
- Position by a window, with a clear outside view avoiding building obstruction, metal structures and power cables
- Place watch on its side
- Keep away from electrical devices especially computers, mobiles, tv's, satellite/cable boxes, kitchen equipment.
- Keep away from electrical lights and light dimmer switches

